



www.alss1.com
 Tel. (860) 643-8401
 Fax (860) 643-9032
 Toll Free (800) 622-8872
 7 Sanrico Dr. • P.O. Box 837
 Manchester, CT 06045-0837
 CT License # 186082

Date: October 7, 2015				
Customer: First Congregational Church of Vernon				
<u>Digital snake channels</u>		<u>Mixing Board channels</u>	<u>Labeled</u>	
		(Page) 1-16		
1	Wireless handheld #1	1	WHH 1	
2	Wireless handheld #2	2	WHH 2	
3	Robin - wireless headset #3	3	Robin	
4	Meg- wireless headset #4	4	WHEAD2	
5	Wireless headset #5	5	WHEAD3	
6	Pulpit	6	Pulpit	
7	Un-used	7	Piano	
8	Un-used	8	Solo	
9	Un-used	9	Blank	
10	Un-used	10	Blank	
11	Piano	11	Blank	
12	Solo mic	12	Blank	
13	Choir 1	13	Chr 1	
14	Choir 2	14	Chr 2	
15	Hanging Mics	15	HangM	
16	Hanging Mics	16	HangM	
		(Page) 17-32	<u>Patched</u>	
		17	Mixer Input 1	
		18	Mixer Input 2	
		19	Mixer Input 3	
		20	Mixer Input 4	
		21	Mixer Input 5	
		22	Mixer Input 6	
		23	Mixer Input 7	
		24	Mixer Input 8	
		25	Mixer Input 9	
		26	Mixer Input 10	
		27	Mixer Input 11	
		28	Mixer Input 12	
		29	Dock L	For Ipad
		30	Dock R	For Ipad
		31	CH23	
		32	CH24	

<u>Output</u>	<u>Labeled</u>	<u>What it does</u>	<u>Where it goes</u>
Aux 1	Chr/Pl	Send to Choir and pulpit monitors	Choir and pulpit monitors
Aux 2	Mdirec(tor)	Send to Music Director	Music directors powered monitor
Aux 3	Post V	Send to video only for Channel 1 - 11	Mtx 1+2
Aux 4	Post V	Send to video only for Channel 1 - 11	Mtx 1+2
Aux 5	Chr1-V	Choir mic video send	Mtx 1+2
Aux 6	Chr1-V	Choir mic video send	Mtx 1+2
Aux 7	Solo-V	Solo mic video send	Mtx 1+2
Aux 8	AUX8	Un-used	
DCA	Controls channel(s)		
1	Aux 5 + 6 to Mtx 1+2	Choir mics to video Mtx 1+2	
2	Ch 15 + 16	Hanging mics to video Mtx 1+2	
3	Aux 7 to Mtx 1 + 2	Solo mic to video Mtx 1+2	
4	Ch 13 + 14	Choir mics to MAIN	
5	Mtx 1 + 2	Video Master level, Mtx 1+2	
6	Aux 3+4 to video	Channels 1 - 12 LESS SOLO (Ch8) to video Mtx 1+2	
7	Un-used		
8	Un-used		
	Digital Snake Outputs		
1	Mono output	<i>To all speakers except monitors</i>	
2	Choir/pulpit monitor		Chr/Pl
3	To balanced send for music director		Mdirec
	Mixing Board outputs - On rear of mixer		
1	Video Left	XLR out	Vid L
2	Video Right	XLR out	Vid R
3	Video Left	XLR out	Vid L
4	Video Right	XLR out	Vid R
5	Video Left	XLR out	Vid L
6	Video Right	XLR out	Vid R
7		Not patched	
8		Not patched	
9	Video Left	Balanced TRS out	
10	Video Right	Balanced TRS out	